

# HOSS

## Disk Harrow Instructions

1. Your Disk Harrow will come with three nuts and bolts. Using these three nuts and bolts, your Disk Harrow will attach to the tool bar of your Wheel Hoe at the locations identified by the three red arrows in the photo on the right.
2. The push pin directional setting controls identified by the black arrows should be nearest to the handles, not closest to the wheel(s).
3. The push pin directional setting controls (black arrows) are used to rotate both sets of three disks inward or outward. Simply pull the pin out, rotate the disk set to the desired directional setting, and place the pin in the matched up hole.
4. The pin may be placed in either of the four holes on the top plate of the Disk Harrow, as long as the top hole matches up with the bottom hole. Note, the angle for each set of disks must be the same on both sides, otherwise it will not push straight.
  - a. Set Disk Harrow blades straight forward for breaking up stems and clods.
  - b. Set Disk Harrow blades at a medium angle for general cultivating.
  - c. Set Disk Harrow blades at a deep angle for moving soil.

